



FOOD

# MF180

## UPRIGHT DISPLAY FREEZER

Vestfrost Solutions MF 180 is used to display frozen items of food. The frost-free freezer defrosts automatically at regular intervals, thus preventing stored items from being covered in frost or sticking to each other. The heated door ensures that the glass is kept free of condensation and secures visibility.



-16°C  
-19°C

### DIMENSIONS

Dimensions HxWxD, mm	1860x600x595
Packaging dimensions HxWxD, mm	1925x636x671
Packaging weight, kg	-
Weight, kg	90 / 88

### STORAGE

Volume	282 / 135
No. of shelves	5 + 1 no.
Shelf dimension	482x374, 183x215
Shelf material	Steel, PE powder white

### COOLING SYSTEM

Refrigerant / amount, g	R600a / 85
Temperature class	3L2
Energy consumption, kWh/24h	13,751
Noise dB	50
Voltage, V	220-240
Frequency, Hz	50
Temperature range, °C	-16 to -19
Energy class	F

### FEATURES

Light inside top	No
Light in door side(s)	2
Cabinet color	White
Inside color/material	White / PS
Lock	Yes
Electronic display	Yes
Defrost	Frost free